



1. Fuel sender access port recess: .25" wide, .1" deep.
2. Cargo box to frame mounting: .5" step bolts with 3" OD washers recessed flush.
3. Cargo box width: 48.5", 6 floor boards on 8" centers.
4. .25" spacing between cargo box vertical boards and exterior edge of floor.
5. .1" recessed lip along exterior floor boards and along the top.
6. .1" recess for bed strips.